GLOBAL WiFi®

NINJA WiFi
Powered by GLOBAL WiFi

WIFI-HIRE.COM

User Manual（303ZT）

データ通信量
SSID
10
お知らせ
ON
14
インターネットWi-Fi
接続数
設定
Pocket WiFi

303ZT（WiFi Router）

Micro-USB cable

AC adaptor

eneloop
Panasonic
QE-PL201

External Battery
(Optional accessory)

Triple Adaptor
(Complimentary accessory)
*Comes free when ordering
other optional services.

The micro-UBS cable may or may not be removable from the AC adaptor.
In the case of multiple orders, multiple accessories can be provided.
The shapes and colors of the accessories may differ from those seen in the photos.

Thank You!

Thank you for choosing Our Service.
This is the user manual for your device. Please read this manual carefully as it contains information on how to operate your device. If you run into any problems during your rental period, please feel free to contact us with the information below.

⚠ Please Note:

[Air Travel] Luggage regulations
Some airports may regulate the number of lithium batteries carried by passengers (often no more than 2).
Also, please place any batteries within your carry-on baggage.

[Settings] User settings
Please make sure you turn off any data roaming functions.

iPhone (iOS7 and later)	1. Settings -> 2. Cellular Data -> 3. Off
Android(Android 4.0 and later)	1. Settings -> 2. Other Settings (Other Networks) -> 3. Mobile network settings ->4. Data roaming -> 5. Off

[Use] When using the device
1. Please do not turn on the device outside of the applied country(s).
   Additional fees may be charged if the user connects from a country not listed within the agreement.
2. Please refrain from over-using the mobile router. Under general fair use policy (fair use of telecommunication devices), users may be subject to slow-downs or disconnects if internet abuse has been detected.
   Some cases may also result in additional fines.
3. Turn off the auto communication functions on your device(s)
   The following functions may utilize large amount of data through auto communication.
   Please set these functions to Off before traveling.
   iPhone (iOS) --- iCloud Photo Steaming, Android --- Auto Update, Windows --- Windows Update

WiFi Rental Customer Support Center
TEL : ＋81-50-5533-8264　E-mail : info@ninjawifi.com
[Business Hours 10:00am-7:00pm(JST)]

Troubleshooting



① Unable to connect to the Internet.

Please check whether or not the icons (globe icon/arrow/4G LTE/3G H, etc.) are being displayed.

Missing icons may be caused by being in an area with weak signal.

<Areas with weak signal>

- High-rise buildings (may be beyond reach if higher than most radio towers).
- Moving vehicles (poor reception due to constantly switching between stations).
- Rural areas (may be far away from the nearest radio station).
- Crowded areas (other signals might interfere with your communication).

<Environments that might cause difficulties> (with reports of unidentifiable SSID or connection cut offs)

- Apple smart devices prior to iOS 8.2.
- When Bluetooth devices are in use.

If experiencing signal issues, many can be resolved by entering a new area or waiting for the interference to subside.

② The router was working perfectly until the connection suddenly cuts off.

If this becomes a persisting issue, please try the following.

1. Reinsert the battery
   Try rebooting the system after reinserting the battery.
2. Reinsert the SIM card
   Rebooting the system after reinserting the SIM card.
3. Reset the system
   With the power still on, open the back cover. Press and hold the reset button for 3 seconds with a pointed object.

Router Overview


①Display
DATA MAIN 4G
100%
データ通信量
SSID
10
お知らせ
ON
インターネットWi-Fi
14
接続数
設定
Pocket WiFi


②Power button
③Lock button
Top
Bottom
④Charging port
⑤SIM card slot

No	Name	Description
①	Display	Status display. Controllable by touchscreen.
②	Power button	Slide to power on/off.
③	Lock button	Turn on/turn off the display screen.
④	Charging port	Please plug the supplied cable in to this port for charging.
⑤	SIM card slot	The SIM card can be removed using a pin or similar objects.

Display Overview


①
DATA MAIN 4G
100%
②
データ通信量
③
SSID
④
10
お知らせ
⑤
ON
インターネットWi-Fi
⑥
14
接続数
⑦
設定

No	Name	Description
①	Icon display	The router's current status is displayed through icons. The meaning of each will be explained during the next section.
②	Data traffic	Shows the amount of data that has been used. Please make sure to reset the device before using this function.
③	SSID	Displays the SSID and Password used to connect to the device.
④	Notification	Not being used.
⑤	Internet Wi-Fi	Displays the current settings for Internet Wi-Fi (mobile network) or Softbank Wi-Fi hotspot. This mobile router is equipped with Carrier Aggregation functionality. High speed connection is available when both networks are connected.
⑥	WiFi connection	Indicates the number of connected devices.
⑦	Settings	Adjusts various settings. Please note that the wrong settings may result in faulty connections.

Internet Wi-Fi (mobile network)			
📶 📶	Signal strength (mobile)	🌐	Initiating connection
DATA MAIN	Connected carrier name	🌐	Connecting
4G 3G	Connection type (4G/3G)	🌐	Connected
圏外	Signal out of range	🌐	Not connected

Softbank Wi-Fi hotspot	
📶 .	Signal strength (hotspot)
Battery	
%	Amount of charge left (in 10% units)
🔋	Charging

How to Connect to Wi-Fi on Android

STEP① Turn on the WiFi router. Step ② onward will be explaining how to connect from your device.

STEP② Turn on the device you wish to connect. Select "settings" from the menu.



STEP③ Switch the Wi-Fi button to "ON".


接続
マイデバイ..
アカウント
その他
ネットワーク接続
Wi-Fi
Bluetooth
通信制限モード
電話の着信とSMSの受信を除いた全ての通信手段を無効にする
データ使用量
その他ネットワーク

←OFF


接続
マイデバイ..
アカウント
その他
ネットワーク接続
Wi-Fi
Bluetooth
通信制限モード
電話の着信とSMSの受信を除いた全ての通信手段を無効にする
データ使用量
その他ネットワーク

←ON

STEP④ After turning on Wi-Fi, your device will search for the list of available networks.

Please check the SSID code labeled on your Wi-Fi router. On your device, select the network named after the same code.


Wi-Fi
Wi-Fiネットワーク
スキャン中..
Verizon-MiFi6620L-222
セキュリティ保護
LGU+Router_9876
セキュリティ保護
GlobalWiFi99999
セキュリティ保護
VisionMobile12345
セキュリティ保護
HWD11_33333333
セキュリティ保護

STEP⑤ A password is required to connect. Enter the password on the router's label, and select "connect".


Wi-Fi
Wi-Fiネットワーク
パスワード
••••••••••••••••••••
□ パスワードを表示
□ 拡張オプションを表示
キャンセル
接続
セキュリティ保護
VisionMobile12345

STEP⑥ Once connected, a notice will appear below the SSID.

At this point, you should be able to access the Internet.


Wi-Fi
Wi-Fiネットワーク
GlobalWiFi99999
接続
VisionMobile12345
セキュリティ保護
Verizon-MiFi6620L-222
セキュリティ保護
LGU+Router_9876
セキュリティ保護

How to Connect to Wi-Fi on iPhone/iPad (iOS)

STEP① Turn on the WiFi router. Step ② onward will be explaining how to connect from your device.

STEP② Turn on the device you wish to connect. Select "settings" from the home menu.



STEP③ Select "Wi-Fi" from the settings menu.


設定
Wi-Fi
機内モード
Wi-Fi オフ
Bluetooth オフ
モバイルデータ通信 オフ
Wi-Fi

←OFF

STEP④ Switch the Wi-Fi button to "ON".
After turning on Wi-Fi, your device will search for the list of available networks.


設定
Wi-Fi
機内モード
Wi-Fi 接続されていません
Bluetooth オフ
モバイルデータ通信 オフ
通知
コントロールセンター
おやすみモード
Wi-Fi
ネットワークを選択...
その他...
接続を確認

接続したことのあるネットワークに自動的に接続します。接続したことのあるネットワークが見つからない場合は、手動でネットワークを選択する必要があります。

←ON

←The circular icon will spin
as your device search for connections.

STEP⑤ Please check the SSID code labeled on your Wi-Fi router. On your device,
select the network named after the same code.


設定
Wi-Fi
機内モード
Wi-Fi 接続されていません
Bluetooth オフ
モバイルデータ通信 オフ
通知
コントロールセンター
おやすみモード
ネットワークを選択...

GlobalWiFi99999
HUAWEI-E5372-AAAA
Verizon-MiFi6620L-222
MobileWiFi-111a
LGU+Router_9876
VisionMobile12345
HWD11_33333333

STEP⑥ A password is required to connect. Enter the password on the router's label, and select "connect".


iPad
12:12
84%
設定
Wi-Fi
機内モード
Wi-Fi 接続されていません
Bluetoo
モバイ
通知
コント
おやす
一般
画面表
壁紙
サウン
パスコ
プライ
Wi-Fi
ネットワークを選択...
"GlobalWiFi99999"のパスワードを入力
キャンセル
パスワード入力
接続
パスワード ●●●●●●●●●
1 2 3 4 5 6 7 8 9 0
- / : ; ( ) ¥ & @ 接続
#+= 取り消す . , ? ! ' " #+=
ABC ABC

STEP⑦ Once connected, the SSID code will be shown next to "Wi-Fi", followed by a checkmark.

At this point, you should be able to access the Internet.


設定
機内モード
Wi-Fi GlobalWiFi99999
Bluetooth オフ
モバイルデータ通信 オフ
Wi-Fi
Wi-Fi
✓ GlobalWiFi99999
ネットワークを選択...
HUAWEI-E5372-AAAA
Verizon-MiFi6620L-222

How to Connect to Wi-Fi on Windows PC

These instructions are written with the assumption that your device(s) is able to access wireless Internet.
In the instance where your device(s) cannot connect to any Wi-Fi hotspots, please contact the maker(s) of your device(s).

STEP① Turn on the WiFi router. Step ② onward will be explaining how to connect from your device.

STEP② Turn on the device you wish to connect. Please note that the following procedures may differ depends on your OS.

Windows7

Windows8

Select "Settings".



STEP③ Select the "signal" icon.


00:00
2015/01/01


スタート
設定
ヘルプ
利用可能
67
100
通知
シャットダウン
言語
PC の詳細設定

STEP④ The list of available networks will be shown.


接続されていません
接続は使用可能です
ワイヤレス ネットワーク接続
GlobalWiFi99999
HUAWEI-E5372-AAAA
Verizon-MiFi6620L-222
MobileWiFi-111a
LGU+Router_9876
VisionMobile12345
HWD11_33333333
ネットワークと共有センターを開く


ネットワーク
フライト モード
オフ
Wi-Fi
GlobalWiFi99999
Verizon-MiFi6620L-222
MobileWiFi-111a
VisionMobile12345

STEP ⑤ Please check the SSID code labeled on your Wi-Fi router. On your device, select the network named after the same code.


接続されていません
接続は使用可能です
ワイヤレス ネットワーク接続
GlobalWiFi99999
接続(C)
HUAWEI-E5372-AAAA
Verizon-MiFi6620L-222
MobileWiFi-111a
LGU+Router_9876
VisionMobile12345
ネットワークと共有センターを開く


ネットワーク
フライト モード
オフ
Wi-Fi
GlobalWiFi99999
☑ 自動的に接続する
接続(C)
Verizon-MiFi6620L-222
MobileWiFi-111a
VisionMobile12345

STEP ⑥ A password is required to connect. Enter the password on the router's label.

Select "OK".


ネットワークに接続
ネットワーク セキュリティ キーを入力してください
セキュリティ キー(S):
☐ 文字を非表示にする(H)
OK
キャンセル

Select "Next".


ネットワーク
GlobalWiFi99999
ネットワーク セキュリティ キーを入力してください
ルーターのボタンを押しても接続できます。
次へ(N)
キャンセル

Select "No" when asked about network sharing.


ネットワーク
GlobalWiFi99999
PC 間の共有を有効にしてこのネットワークのデバイスに接続しますか?
いいえ、共有を有効にしてデバイスに接続しません
公共の場所にあるネットワークの場合
はい、共有を有効にしてデバイスに接続します
ホーム ネットワークや社内ネットワークの場合

STEP ⑦ Once connected, a "connected signal" icon will be displayed.
At this point, you should be able to access the Internet.


A 般
CAPS
KANA
00:00
2015/01/01

How to Connect to Wi-Fi on Mac

These instructions are written with the assumption that your device(s) is able to access wireless Internet.
In the instance where your device(s) cannot connect to any Wi-Fi hotspots, please contact the maker(s) of your device(s).

STEP① Turn on the WiFi router. Step ② onward will be explaining how to connect from your device.

STEP② Turn on the device you wish to connect. Select the Wi-Fi icon (AirMac) on the status bar.

Wi-Fi Available		
WiFi Not available		

STEP③ After turning on Wi-Fi, your device will search for the list of available networks.
Please check the SSID code labeled on your Wi-Fi router. On your device, select the network named after the same code.



Wi-Fi：入
Wi-Fi を切にする
ネットワーク未選択
VisionMobile12345
Verizon-MiFi6620L-222
LGU+Router_9876
MobileWiFi-111a
GlobalWiFi99999
ほかのネットワークに接続...
ネットワークを作成...
"ネットワーク"環境設定を開く...

STEP④ A password is required to connect. Enter the password on the router's label, and select "connect".



Wi-Fi ネットワーク “GlobalWiFi99999” には
WPA パスワードが必要です。

パスワード：•••••••••

☐ パスワードを表示
☑ このネットワークを記憶

STEP⑤ Once connected, a checkmark will appear to the left of the SSID code.
At this point, you should be able to access the Internet.



Wi-Fi：入
Wi-Fi を切にする
ネットワーク未選択
VisionMobile12345
Verizon-MiFi6620L-222
LGU+Router_9876
MobileWiFi-111a
✓ GlobalWiFi99999
ほかのネットワークに接続...
ネットワークを作成...
"ネットワーク"環境設定を開く...

How to use the external battery

enep
enep
enep

Panasonic
Panasonic

We provide two types of external battery: enep and Panasonic QE.
The shapes and colors of the batteries may differ from those seen in the photos.

The layout on the side of the battery is universal among brands.
Please be aware of the adaptor's direction when connecting the UBS-to-micro-USB cable.

When charging the external battery (receiving charges).



Micro-USB

+



+



+



When charging other devices (delivering charges).



USB

+



+

UNITE-2033
29382102

WiFi Router

Or

your device

The battery comes with 2 USB ports, making it possible to charge 2 devices simultaneously.
After linking the device(s) to the battery, press the on/off button, and make sure the device is being charged.
The required charge time may be longer with 2A devices like iPads and tablets.

LED Signals

The LED light will display different colors depends on the situation,
the signals are as follow:

enep

LED	Blue	Red	Off
receiving charges	- (※)	Charging	Charging complete
delivering charges	Delivering charges	-	Device off

※ Certain models of the battery will turn on blue instead of red when charging.
※ enep external batteries will automatically turn off its LED light after 7 seconds.

Panasonic QE

LED	Green	Orange	Red	Red (flashing)	Off
receiving charges	Amount of charge left 100%-60%	Amount of charge left 59%-30%	Amount of charge left 29% or less	Error	Charging complete
delivering charges	Amount of charge left 100%-60%	Amount of charge left 59%-30%	Amount of charge left 29% or less	-	Device off

When charging the external battery (receiving charges):
The battery, along with the LED light, will turn on when connected.
Fully charging the external battery will take roughly 7 hours.

When charging other devices (delivering charges):
To charge other devices, press the large button after connecting the battery.
Fully charging another device from the external battery will take roughly 2 hours
(2000mAh capacity, 5V 1A output).